



FUSELAGE CONSTRUCTION
 CUT OUT SIDES AND TOP AND PIN DOWN AS IN FIG. 1. DOPE TISSUE ON, GIVING TWO COATS. WHEN DRY THE TISSUE ACTS AS A HINGE AND HELPS TO ALIGN THE FUSELAGE SIDES. ASSEMBLE BEARER UNIT AND INSERT IN FUSELAGE. SLOT TOP FOR PYLON POST AND T.E. ADD L.E. P-1, P-2 AND P-3. SHEET PYLON SIDES WITH 1/16\"/>

HI-TEE Mk. 14.

OCTOBER 1964.

