



(NOTE: USE PLIOBOND CEMENT OR GOO TO FASTEN RECEIVER TO FOAM RUBBER AND TO FASTEN THE RUBBER TO F-1)

